


QUICK START GUIDE

RAM 1500





Garage Door Opener

Overhead Lights/Sunroof/
Rear Window Controls

Digital Rearview Mirror

Instrument Cluster Display &
Voice Recognition Buttons

Cruise Control Buttons/
Active Driving Assist

Power Seat
Controls/
Memory Buttons

Passenger Screen

Power Seat
Controls/
Memory Buttons

AUX/USB Ports (C/A)

Wireless Charging Pad

Light Controls

Electronic Range
Selector

4WD/Shift
Controls

Integrated Trailer
Brake Module

Garage Door Opener



- 1 With the vehicle in the ACC or ON/RUN position, hold the garage door transmitter 1-3 inches from the HomeLink® button you want to program.
- 2 Push and hold the HomeLink® button and the button on the garage door transmitter.
- 3 **Watch the indicator light.**
If it turns solid or blinks rapidly and the door operates programming is complete.
If it blinks rapidly but the garage door doesn't operate, continue to step 4.
- 4 For **Rolling Code** garage door openers, push the "Learn", "Program", "Smart", or "Train" button on your garage door opener, then push and hold the HomeLink® button in your vehicle up to three times (holding for two seconds each time).
- 5 If programming was successful, your garage door will open and close with the HomeLink® button.

TO ERASE ALL SET CHANNELS:

Push and hold the two outside HomeLink® buttons until the indicator flashes.



ROLLING OR NON-ROLLING

Check your garage door opener motor in your garage for a "Learn", "Program", "Smart", or "Train" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.



NEED ASSISTANCE?

1-800-355-3515

Scan For
HomeLink®
Video



Pair a Phone



- 1 Make sure Bluetooth® is enabled on your mobile device
- 2 With the vehicle in the ON/RUN position, press the Phone button on the vehicle's touchscreen menu bar
- 3 Press "Device Manager"
- 4 Press "Add Device"
- 5 Follow the prompts on your phone and on the touchscreen

Troubleshooting

- 1 Perform a reset by holding the power button on the radio for 15 seconds
- 2 Reboot your phone
- 3 Remove the paired phone
- 4 Follow the Pair a Phone steps above to set up phone



Scan For
Android™ Auto
Video



Scan For
Apple Carplay®
Video



Connected Services

WITH CONNECTED SERVICES YOU CAN...



Lock Your Vehicle



Unlock Your Vehicle



Remote Start Your Vehicle



Cancel Remote Start



Activate Your Horn

ACTIVATE YOUR REMOTE SERVICES



- 1 Press "Apps" on the touchscreen.
- 2 Press "Activate Services".
- 3 Press "Activate Now".
- 4 You can activate via email or an agent. Press "Call An Agent" to speak with an agent. If you were registered for Connected Services at the dealership, simply enter your email and PIN to activate them.
- 5 Download the Ram Mobile App from the Google Play® Store or Apple® App Store® for access to Remote Commands. Log in with your account information.



Mopar® YOUR Way

Get 24/7 access to everything you need, including custom vehicle dashboards, maintenance records, mobile vehicle commands and more. Scan the QR code to register.



*Canadian residents are not required to create a profile, as one is created when a Ram Connect account is activated.

Uconnect 5/5 NAV

Available Modes:


- **Home:** Customize the Home screen with widgets
- **Media:** Listen to the radio and play media
- **Navigation:** Search for and navigate to any destination
- **Comfort:** Adjust the vehicle's multiple climate systems
- **Phone:** Pair your smartphone and make hands-free calls
- **Vehicle:** Change vehicle settings
- **Apps:** Select from available apps

Voice Recognition

Use Your Voice To Control Uconnect To begin, push the Voice Recognition button on the steering wheel. If activated within Vehicle settings, you can also say the vehicle's "Wake Up" word, "Hey, Uconnect" or "Hey, Ram", without pushing any buttons.



Swipe down to customize Profile options



Press and drag an icon to rearrange

Scan For
Radio Video



Scan For
Navigation
Video



Scan For Voice
Recognition
Video



Wireless Charging Pad

The **wireless charging pad** is equipped with an anti-slip mat to hold your mobile phone in place, and an LED indicator light.



No Light: Charging pad is idle or searching for a device.



Blue Light: Device is detected and is charging.



Red Light/Flashing: Internal error, or foreign object is detected.



Green Light: Device has completed battery charging.
(If device is equipped to transmit this information).

Note:

For the wireless pad to work properly

Remove the phone's protective case and place the phone within the outline shown on the pad.

KEEP IN MIND:

- The charging pad will not work if any door is open, regardless if the engine is running.
- Having multiple applications open on the phone will reduce charging efficiency.
- In the event the phone starts to overheat, the phone may shut down during the charging process.

Scan For
Wireless Charging
Pad Video



Trailer Reverse Steering Control (TRSC)

IF EQUIPPED, TRAILER REVERSE STEERING CONTROL WILL ASSIST THE DRIVER WHEN BACKING UP A TRAILER

To activate the system:

- Place the vehicle in Park and put your foot on the brake.
- Push the activation button above the TRSC knob and the system will direct you to shift into reverse.
- Once in reverse, the LED on the button will illuminate indicating the system is active.

To use the system:

- Remove your hands from the steering wheel and turn the TRSC knob the direction you want to go, while slowly backing up.
- If you release the knob, use the PUSH TO CENTER button to center the trailer.
- To cancel the feature, place the vehicle in Park or push the TRSC button.

Scan for
TRSC Video



Trailer Light Check

Available in Uconnect System under the Trailer Tow pages. Once activated, the light check enables all of the exterior lights sequentially for up to five minutes.

The following conditions must be met for activation:

- Vehicle is equipped with Trailer Brake Control
- Vehicle is in PARK
- Vehicle is in ON/RUN
- Remote Start is not active
- Brakes are not applied
- Turn signals are not applied
- Hazard lights are not on

Camera Systems

Available Camera Features:

- Rear Back Up Camera
- Surround View Camera
- Trailer Surround View
- Auxiliary Cameras



Pressing the **Trailer Reverse Guidance** button provides a full screen view of the cargo area and trailer.



Pressing the **Left & Right Tow Mirror Split Screen View** button within the Trailer Reverse Guidance screen displays a split screen view of both sides of the trailer.

Scan For Camera
Systems Video



Ram Digital Key

YOUR VEHICLE MAY BE EQUIPPED WITH THE ABILITY TO USE YOUR iPhone® OR ANDROID™ DEVICE AS A DIGITAL KEY


With the paired Digital Key on your iPhone® or Android™ device, you can lock, unlock, and start your vehicle with ease!

To enable Digital Key, ensure your vehicle has been enrolled in Ram Connect and you have created your Owner Account (same credentials used to access your Ram app). To set up the feature in your vehicle:

- Within the Uconnect App drawer, select “Digital Key App”.
- Select “Add Owner Key”.
- Click the Digital Key tile in the Ram App and tap “Start Pairing” to begin the key pairing process.
- To pair, place iPhone® or Android™ device on the wireless charging pad ensuring that the NFC antennas are aligned.
- “Digital Key Successfully Added” will appear on-screen.



Depending on your device, you may need to hold the iPhone® or Android™ device against the drivers door handle and NFC capable wireless charging pad to access and start the vehicle. iPhone® or Android™ device's without UWB (Ultra-wideband) technology will not support hands-free vehicle access and start functionality.



Scan for
Digital Key Video




Hands-Free Mode

COMBINES ACTIVE LANE MANAGEMENT AND ADAPTIVE CRUISE CONTROL

Hands-Free ADA system has two operating modes: Hands-On Mode and Hands-Free Mode.

Hands-On Mode uses driver attentiveness and requires hands on the steering wheel.

Hands-Free Mode uses sensors within the steering wheel and a driver monitoring camera located on top of the steering column to monitor driver attentiveness. Hands-Free mode allows the driver to remove their hands temporarily from the steering wheel, when the system is engaged, on approved roadways.



Scan For
Hands-Free Video



Digital Cluster

Your instrument cluster displays important and useful information about your vehicle and can be customized using the steering wheel controls.



Power Tailgate

Lower or raise the **Power Tailgate** with a push of a button.

Open or close the tailgate using your:

- Overhead Console Button
- Key Fob
- Outside Handle (open or reset tailgate latch)
- Left Side Tailgate Switch (closing only)
- Tip-To-Close

Scan for
Power Tailgate
Video



Warning & Indicator Lights

	Air Bag		Battery Charge		Brake		Door Open		Drowsy Driver
	Electronic Throttle Control (ETC)		Engine Coolant Temperature		Hood Open		Oil Pressure		Oil Temperature
	Seat Belt Reminder		Trailer Brake Disconnected		Tailgate Open		Transmission Temperature		Vehicle Security
	4WD LOCK		4WD HIGH		4WD LOW		Adaptive Cruise Control (ACC) Fault		Air Suspension Fault
	Air Suspension Payload Protection		Air Suspension Lowering		Air Suspension Raising		Anti-Lock Brake System (ABS)		Cargo Light
	Cruise Control Fault		Electronic Stability Control (ESC) Active		Electronic Stability Control (ESC) OFF		Forward Collision Warning (FCW) OFF		Front And Rear Axle Lock
	Low Washer Fluid		NEUTRAL		Rear Axle Lock		Rear Axle Locker Fault		SERVICE 4WD
	Service Forward Collision Warning (FCW)		Service Active Lane Management		Snowplow Mode		SWAY BAR		SWAY BAR Fault
	Tire Pressure Monitoring System (TPMS)		TOW/HAUL		Trailer Merge Assist		Adaptive Cruise Control (ACC) Set With No Target		Adaptive Cruise Control (ACC) Set With Target
	Cruise Control Set		ECO Mode		Front Fog Lights		Parking/Headlights		Turn Signal
	Adaptive Cruise Control (ACC) Ready		Cruise Control Ready		Hill Descent Control (HDC)		High Beam		

RAM Customer Assistance: (866) 726-4636 (US), (800) 465-2001 (CANADA)

Your vehicle may be equipped with different features than shown in this guide.

For additional information on any of the topics in this publication, please refer to your digital Owner's Manual.

©2025 FCA US LLC. All Rights Reserved. Tous droits réservés. Ram is a registered trademark of FCA US LLC. Ram est une marque déposée de FCA US LLC. App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

Third Edition
26_DT_QSG_EN_USC