



2023 OWNER HANDBOOK

This Owner Handbook illustrates and describes the operation of features and equipment that are either standard or optional on this vehicle. This manual may also include a description of features and equipment that are no longer available or were not ordered on this vehicle. Please disregard any features and equipment described in this manual that are not on this vehicle. FCA US LLC reserves the right to make changes in design and specifications, and/or make additions to or improvements to its products without imposing any obligation upon itself to install them on products previously manufactured.

With respect to any vehicles sold in Canada, the name FCA US LLC shall be deemed to be deleted and the name FCA Canada Inc. used in substitution therefore.

This Owner Handbook is intended to familiarize you with the important features of your vehicle. Your most up-to-date Owner Handbook, Owner's Manual, Radio Instruction Manual and Warranty Booklet can be found by visiting the website on the back cover.

U.S. Residents: If you are the first registered retail owner of your vehicle, you may obtain a complimentary printed copy of the Warranty Booklet by calling **1-800-247-9753** or by contacting your dealer. Replacement kits can be purchased by visiting www.techauthority.com.

Canadian Residents: If you are the first registered retail owner of your vehicle, you may obtain a complimentary printed copy of the Warranty Booklet or purchase a replacement kit by calling **1-800-387-1143** or by contacting your dealer.

ROADSIDE ASSISTANCE

24 HOURS, 7 DAYS A WEEK AT YOUR SERVICE.

CALL 1-800-521-2779 OR VISIT CHRYSLER.RSAHELP.COM (USA)

CALL 1-800-363-4869 OR VISIT FCA.ROADSIDEAID.COM (CANADA)

SERVICES: Flat Tire Service, Out Of Gas/Fuel Delivery, Battery Jump Assistance, Lockout Service and Towing Service

Please see the Customer Assistance chapter in this Owner Handbook for further information.

FCA US LLC reserves the right to modify the terms or discontinue the Roadside Assistance Program at any time. The Roadside Assistance Program is subject to restrictions and conditions of use, that are determined solely by FCA US LLC.



WARNING: Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.



1

INTRODUCTION
Page 4



2

INTERIOR
Page 8



3

EXTERIOR
Page 32




4

EMERGENCY
Page 35



5

SPECIFICATIONS
Page 44



6

INDEX
Page 49

INTRODUCTION

OWNER HANDBOOK INTRODUCTION	4
SYMBOLS KEY	4
CUSTOMER ASSISTANCE	5
FCA US LLC Customer Center	5
FCA Canada Inc. Customer Center	5
Mexico	5
Puerto Rico And US Virgin Islands	5
ROADSIDE ASSISTANCE	5
Customer Assistance For The Hearing Or	
Speech Impaired (TDD/TTY)	5
Service Contract	6
Warranty Information	6
Ordering and Accessing Additional Owner's	
Information	6
Change Of Ownership Or Address	7
General Information	7

INTERIOR

INTERIOR OVERVIEW	8
STARTING AND OPERATING	9
Key Fob	9
Keyless Enter 'n Go™ — Passive Entry	10
MULTIMEDIA & PHONE CONNECTIVITY	11
Uconnect System	11
Uconnect Settings	12
Pair/Delete A Device	12
Apple CarPlay®	13
Android Auto™	14

Uconnect Voice Recognition	14
Performance Pages	14
Drive Modes	15
CHARGING & OUTLETS	16
USB	16
INSTRUMENT CLUSTER	17
Getting To Know Your Instrument	
Cluster	17
Controlling Your Instrument Cluster	
Display	18
Warning Lights And Messages	18
INTERIOR COMFORT SETTINGS	22
Climate Controls	22
Automatic Climate Control Descriptions And	
Functions	22
Automatic Temperature Control (ATC)	23
Climate Voice Recognition	23
Front Heated Seats	23
Front Ventilated Seats	23
Power Front Seats	24
Driver Memory Settings	24
Head Restraints	25
LIGHTING OPERATION	26
Headlight Switch	26
Automatic High Beams	26
Automatic Headlights	26
Automatic Headlights With Wipers	26
WINDSHIELD WIPERS & WASHERS	27
Windshield Wiper Operation	27
Rain Sensing Wipers	27

CRUISE CONTROL SYSTEMS	28
Adaptive Cruise Control (ACC)	28
GARAGE DOOR OPENER (HOMELINK®)	30
Troubleshooting Tips	30
PARKING ASSISTANCE	31
Parksense Front/Rear Park Assist	
System	31

EXTERIOR

EXTERIOR OVERVIEW	32
EXTERIOR CAMERA VIEWS	33
Back Up Camera	33
TRUNK	33
Trunk Release Button	33
REFUELING THE VEHICLE	33

EMERGENCY

ASSIST AND SOS SYSTEM — IF EQUIPPED	35
TIRE SERVICE KIT	37
Tire Service Kit Location	37
JUMP STARTING	37
Preparations For Jump Starting	37
Jump Starting Procedure	38
REFUELING IN EMERGENCY	39
FREEDING A STUCK VEHICLE	40
IF YOUR ENGINE OVERHEATS	40
TOWING A DISABLED VEHICLE	41
Towing In An Emergency	42

SPECIFICATIONS

ENGINE COMPARTMENT OVERVIEW	44
6.4L Engine	44
FLUID CAPACITIES	45
FLUIDS AND LUBRICANTS	45
SERVICING AND MAINTENANCE	47
Maintenance Plan	47
Oil Change Reset	47
Engine Break-In Recommendations —	
6.4L	48
TRAILER TOWING	48

OWNER HANDBOOK INTRODUCTION

Thank you for choosing Chrysler. This Owner Handbook has been prepared to help you quickly become acquainted with important features of your vehicle. It contains most things you will need to operate and maintain your vehicle, including emergency information.

This handbook also illustrates and describes the operation of certain features and equipment that come either standard or optional on your vehicle. It may include a description of features and equipment that your vehicle is not equipped with. FCA US LLC reserves the right to make changes in design and specifications and/or make additions to or improvements to its products without imposing any obligation upon itself to install them on products previously manufactured.

Mobile App:



To access your complete Owner's Manual online: www.mopar.com

To order a hard copy of your Owner's Manual, visit:
www.techauthority.com



SYMBOLS KEY

WARNING!	These statements apply to operating procedures that could result in a collision, bodily injury and/or death.
CAUTION!	These statements apply to procedures that could result in damage to your vehicle.
NOTE:	A suggestion which will improve installation, operation, and reliability. If not followed, may result in damage.
TIP:	General ideas/solutions/suggestions on easier use of the product or functionality.
PAGE REFERENCE ARROW 	Follow this reference for additional information on a particular feature.
FOOTNOTE 	Supplementary and relevant information pertaining to the topic.

If you do not read the entire Owner's Manual, you may miss important information. Observe all Cautions and Warnings.

CUSTOMER ASSISTANCE

FCA US LLC and its authorized dealers are vitally interested in your satisfaction. We want you to be happy with our products and services.

Warranty service must be done by an authorized dealer. We strongly recommend that you take the vehicle to an authorized dealer for non-warranty service as well. FCA US LLC's authorized dealers have the facilities, factory-trained technicians, special tools, and the latest information to ensure the vehicle is fixed correctly and in a timely manner.

If your authorized dealer is unable to resolve the concern, you may contact an FCA US LLC Customer Assistance center.

Any communication to an FCA US LLC Customer Assistance center should include the following information:

- Owner's name and address
- Owner's telephone number (home, mobile, and office)
- Authorized dealer name
- Vehicle Identification Number (VIN)
- Vehicle delivery date and mileage

FCA US LLC CUSTOMER CENTER

P.O. Box 21-8004

Auburn Hills, MI 48321-8004

Phone: (800) 247-9753

FCA CANADA INC. CUSTOMER CENTER

P.O. Box 1621

Windsor, Ontario N9A 4H6

Phone: (800) 465-2001 English /
(800) 387-9983 French

MEXICO

Av. Prolongacion Paseo de la Reforma, 1240

Sante Fe C.P. 05109

Mexico, CDMX

In Mexico City: 800-505-1300

Outside Mexico City: +(52) 55 50817568

PUERTO RICO AND US VIRGIN ISLANDS

FCA Caribbean LLC

P.O. Box 191857

San Juan 00919-1857

Phone: (800) 247-9753

ROADSIDE ASSISTANCE

Phone: (800) 521-2779

Available: 24 Hours, 7 Days A Week

- Flat Tire Service
- Out Of Gas/Fuel Delivery
- Battery Jump Assistance
- Lockout Service
- Towing Service

CUSTOMER ASSISTANCE FOR THE HEARING OR SPEECH IMPAIRED (TDD/TTY)

To assist customers who have hearing difficulties, FCA US LLC has installed special Telecommunication Devices for the Deaf (TDD) equipment at its customer centers. Any hearing or speech impaired customer, who has access to a TDD or a conventional teletypewriter (TTY) in the United States, can communicate with FCA US LLC by dialing 1-800-380-2479.

Canadian residents with hearing difficulties who require assistance can use the special needs relay service offered by Bell Canada. For TTY users, dial 711. For Voice callers, dial 1-800-855-0511 to connect with a Bell Relay Service operator.

SERVICE CONTRACT

You may have purchased a service contract for a vehicle to help protect you from the high cost of unexpected repairs after FCA US LLC's New Vehicle Limited Warranty expires. The Mopar® Vehicle Protection plans are the ONLY vehicle extended protection plans authorized, endorsed and backed by FCA US LLC to provide additional protection beyond your vehicle's warranty. If you purchased a Mopar® Vehicle Protection Plan, you will receive Plan Provisions and an Owner Identification Card in the mail within three weeks of the vehicle delivery date. If you have any questions about the service contract, call FCA US LLC's Service Contract National Customer Hotline at 1-800-521-9922.

For Canadian residents, you may have purchased additional coverage with an extended service contract. FCA Canada Inc. stands fully behind its service contracts. Be sure that the one you buy is a genuine Canada Inc. service contract. We are not responsible for other companies' contracts. If you purchased a contract other than a genuine FCA Canada Inc. service contract and you have a problem, you will have to contact the administrator of that contract for resolution. If you have any questions about the service contract, call the FCA's Service Contract National Customer Hotline at (800) 465-2001 English / (800) 387-9983 French).

FCA US LLC is not responsible for any service contract you may have purchased from another manufacturer. If you require service after the FCA US LLC New Vehicle Limited Warranty expires, please refer to the contract documents, and contact the person listed in those documents.

We appreciate that you have made a major investment when you purchased the vehicle. An authorized dealer has also made a major investment in facilities, tools, and training to assure that you are absolutely delighted with the ownership experience.

WARRANTY INFORMATION

To access your warranty information online, visit www.mopar.com/om (US) or www.owners.mopar.ca/en or www.owners.mopar.ca/fr (Canada).

Use this QR code to access your digital experience.



ORDERING AND ACCESSING ADDITIONAL OWNER'S INFORMATION

To order the following manuals, you may use either the website or the phone numbers listed below.

Service Manuals

These comprehensive Service Manuals provide a complete working knowledge of the vehicle, system, and/or components and is written in straightforward language with illustrations, diagrams, and charts.

Diagnostic Procedure Manuals

Diagnostic Procedure Manuals are filled with diagrams, charts and detailed illustrations. These manuals make it easy to find and fix problems on computer-controlled vehicle systems and features. They show exactly how to find and correct problems, using step-by-step troubleshooting and drivability procedures, proven diagnostic tests and a complete list of all tools and equipment.

To order a digital of your Service or Diagnostic Procedure manuals, visit:

www.techauthority.com (US and Canada).

Owner's Manuals

These Owner's Manuals have been prepared with the assistance of service and engineering specialists to acquaint you with specific FCA vehicles.

To access your Owner's Information online, visit www.mopar.com/om (US) or www.owners.mopar.ca (Canada).

Or visit:

www.techauthority.com to order physical copies of Owner's Manuals (US).

Owner's Manuals, Radio Manuals and Warranty Information Books can be ordered through Archway at:

1-800-387-1143 (Canada)

CHANGE OF OWNERSHIP OR ADDRESS

*If you have purchased this vehicle used or have changed your address, please provide the following information and mail to:

FCA US LLC

P.O. Box 21-8008

Auburn Hills, MI 48321-8004

Make sure to include the following:

- Date of Sale (mm/dd/yy)
- Vehicle Identification Number (17 Character ID located on top left of the instrument panel)
- Exact Odometer Reading
- First and Last Name
- Phone Number
- Street Address, City, State and Zip Code
- Email Address

*Applies to US residents only.

GENERAL INFORMATION

The following regulatory statement applies to all Radio Frequency (RF) devices equipped in this vehicle:

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Innovation, Science and Economic Development applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage, et
2. L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

La operación de este equipo está sujeta a las siguientes dos condiciones:

1. Es posible que este equipo o dispositivo no cause interferencia perjudicial y
2. Este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

NOTE:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

INTERIOR OVERVIEW



1 — Garage Door Opener (HomeLink®)

➞ page 30

2 — Assist & SOS Buttons ➞ page 35

3 — Windshield Wipers and Washers ➞ page 27

4 — Instrument Cluster Controls ➞ page 18

5 — Instrument Cluster Display

➞ page 18

6 — Keyless Enter 'n Go™ Ignition ➞ page 10

7 — Uconnect Radio Screen Display ➞ page 11

8 — Headlight Switch ➞ page 26

9 — Uconnect Voice Command Buttons

➞ page 14

10 — Cruise Control Buttons ➞ page 28

11 — Climate Controls ➞ page 22

STARTING AND OPERATING

KEY FOB

Your key fob allows you to lock or unlock all doors and trunk, as well as activate the Panic Alarm.



- 1 — Unlock
- 2 — Lock
- 3 — Trunk
- 4 — Remote Start (If Equipped)
- 5 — Panic
- 6 — Emergency Key

To Remove The Emergency Key

You can remove the emergency key by pushing the release button on the back of the key fob.

To Lock/Unlock The Doors And Trunk

Push and release the unlock button on the key fob once to unlock the driver's door, or push it again to unlock all doors and the trunk. If you want to unlock all the doors with a single push of the unlock button, you can change this setting within your Uconnect system. A push of the lock button will lock all of your doors and trunk.

Remote Start

Push and release the Remote Start button on the key fob twice within five seconds.

Some additional features may automatically activate when using Remote Start:

- Your driver ventilated seat feature may turn on.
- Your front and rear defrost may turn on.
- Your heated steering wheel and driver heated seat feature may also turn on.

WARNING!

- Do not start or run an engine in a closed garage or confined area. Exhaust gas contains carbon monoxide which is odorless and colorless. Carbon monoxide is poisonous and can cause serious injury or death when inhaled.
- Keep key fobs away from children. Operation of the Remote Start system, windows, door locks or other controls could cause serious injury or death.

KEYLESS ENTER 'N GO™ — PASSIVE ENTRY

Keyless Enter 'n Go™ — Passive Entry allows you to lock and unlock the vehicle's door(s) without having to push the key fob lock or unlock buttons.

To Unlock/Lock The Vehicle's Doors And Trunk


With a valid Passive Entry key fob with you, grab the handle to unlock the vehicle. The driver's handle will unlock the driver's door only (unless otherwise programmed in Uconnect Settings), whereas the passenger handle will unlock all doors and the trunk.

With a valid Passive Entry key fob on you, push the Passive Entry lock button on the door handle to lock the vehicle.

NOTE:

DO NOT grab the door handle when pushing the lock button. This could unlock the door(s).

Use this QR code to access your digital experience.



Push The Door Handle Button To Lock

MULTIMEDIA & PHONE CONNECTIVITY

UCONNECT SYSTEM



Uconnect 4C/4C NAV With 8.4-inch Display

1 — Radio/Media Button

2 — Controls Button

3 — Climate Button

4 — Apps Button

5 — Nav Button

6 — Phone Button

7 — Settings Button

NOTE:

Uconnect screen images may not reflect the exact software in your vehicle.

Use this QR code to access your digital experience.



UCONNECT SETTINGS



**Uconnect 4C/4C NAV With 8.4-inch Display
Uconnect Settings**

Do you want to change the theme of your radio? Or what about setting text message pop-up notifications?

These settings are all customizable, and can be adjusted to your needs with a press of your fingertip.

Press the Vehicle button, then press the Settings button toward the top of your touchscreen to get started with customizing your settings.

NOTE:

Depending on the vehicle's options, feature settings may vary.

- **Display** — Customize features such as your display brightness, or even allow navigation instructions to appear on your instrument cluster display!
- **Safety/Driving Assistance** — Would you like to be able to customize your LaneSense feature? Within the Safety/Driving Assistance setting, you can customize both the warning signal and steering wheel strength for your LaneSense detection.
- **Lights** — Customize features such as “Daytime Running Lights”, “Auto Dim High Beams”, and much more!
- **Phone/Bluetooth®** — Do you have your phone paired to your Uconnect system yet? Press the Phone/Bluetooth® button to begin the phone pairing process.
- **Camera** — Pressing the Camera button on the touchscreen will display settings related to the vehicle's cameras. One setting includes “ParkView Backup Camera Delay”.
- **Doors & Locks** — Customize features such as “Auto Unlock On Exit”, “Passive Entry”, “Personal Settings Linked To Key Fob”, and much more!

• **Seats & Comfort** — The Uconnect system allows you to adjust your comfort levels for your heated seats, heated steering wheel, and even ventilated seats!

• **Key Off Options** — The Uconnect system gives you the option to customize what your vehicle does when it shuts down. One option is adjusting how long your headlights stay on after you turn your vehicle off.

• **Audio** — Did you know you can customize your vehicle's audio? Press the Audio button to begin tuning your vehicle's audio to your liking.

Use this QR code to access your digital experience.



PAIR/DELETE A DEVICE

Did you know pairing your smartphone with your vehicle is quick and easy?

Pairing your smartphone with your vehicle will open even more possibilities for your driving convenience, such as playing music from your phone or answering calls through your Uconnect system.

1. Make sure Bluetooth® is enabled on your mobile phone.
2. With the vehicle in the ACC or ON/RUN position, press the Phone button on the vehicle's touchscreen menu bar.

3. Press “Yes” to begin the pairing process.
4. Search for available devices on your Bluetooth®-enabled mobile phone.
5. If “No” is selected, and you still would like to pair a mobile phone, press the Phone Pairing or Settings button from the Uconnect Phone main screen.
6. Uconnect Phone will display an in-progress screen while the system is connecting.
7. When your mobile phone finds the Uconnect system, select “Uconnect”.
8. Follow the prompts on your phone and on the touchscreen.



**Uconnect 4C/4C NAV With 8.4-inch Display
Pairing a Phone**

Follow these steps to remove your smartphone:

1. Press the Uconnect Phone Pairing or Settings button.
2. Press the Paired Phone and Audio Devices button and then press Paired Phones or Audio Sources button.
3. Press the Settings button located to the right of the device name for a different phone or audio device than the currently connected device or press the preferred connected phone from the list.
4. The option's pop-up will be displayed.
5. Press the Disconnect Device or the Delete Device button.
6. Press the X to edit out of the Settings screen.

Use this QR code to access your digital experience.



APPLE CARPLAY®

To use Apple CarPlay®, follow these steps:

1. Ensure that your iPhone® is unlocked for the very first connection, then ensure Siri is enabled in settings.
2. Connect your iPhone® to one of the media USB ports in your vehicle, or pair your iPhone® with the system. You have no need to plug your device in if it is paired with the system.
3. Once the device is connected and recognized, the Phone icon on the menu bar changes to the Apple CarPlay® icon.

NOTE:

To use Apple CarPlay®, make sure that cellular data is turned on, and that you are in an area with cellular coverage. Your data and cellular coverage is shown on the left side of the touchscreen. Data plan rates may apply.

Use this QR code to access your digital experience.



ANDROID AUTO™

To use Android Auto™, follow these steps:

1. Download the Android Auto™ app from the Google Play store.
2. Connect your phone to one of the media USB ports in your vehicle, or pair your phone with the system. You have no need to plug your device in if it is paired with the system.
3. Once the device is connected and recognized, the Phone icon on the menu bar changes to the Android Auto™ icon.

NOTE:

To use Android Auto™, make sure you are in an area with cellular coverage. Android Auto™ may use cellular data, and your cellular coverage is shown in the upper right corner of the touchscreen. Data plan rates may apply.

Use this QR code to access your digital experience.



UCONNECT VOICE RECOGNITION

Introduction

Did you know that your vehicle is capable of voice commands? This feature is called Voice Recognition (VR).

Start using Uconnect VR with these helpful quick tips. They provide the key voice commands and tips you need to know to control your vehicle's VR system.

Basic Voice Commands

The following basic voice commands can be given at any point while using your Uconnect system.

Push the VR button . After the beep, say:

- **"Cancel"** to stop a current voice session.
- **"Help"** to hear a list of suggested Voice Commands.
- **"Repeat"** to listen to the system prompts again.

Notice the visual cues that inform you of your VR system's status on your Uconnect system.

Use this QR code to access your digital experience.



PERFORMANCE PAGES

Your vehicle is equipped with Performance Pages, which is an application that provides a display for performance indicators that will help you gain familiarity with the capabilities of your vehicle in real time.

Press the Apps button on the touchscreen, then press the Performance Pages button. Press the desired button on the touchscreen to access that specific Performance Page.



- 1 — Home
- 2 — Timers
- 3 — Gauges
- 4 — G-Force
- 5 — Engine
- 6 — Dyno

Performance Pages include the following:


- **Home:** Customize widgets such as Oil Temp, Oil Pressure, Coolant Temp, Battery Voltage, and more!
- **Timers:** Displays the Recent, Last, and Best recorded runs of performance timers.
- **Gauges:** Displays the values of Oil Temp, Oil Pressure, Coolant Temp, Battery Voltage, and more!
- **G-Force:** Displays front, right, left, and rear G-Force values, as well as steering angle.
- **Engine:** Displays the values of Engine Power, Engine Torque, Oil Pressure (6.4L only), Boost Pressure (6.2L only), and more!
- **Dyno:** Displays a graph for Power and Torque, as well as Engine Speed.

DRIVE MODES

Your vehicle is equipped with a Drive Modes feature which allows for coordinating the operation of various vehicle systems depending upon the type of driving behavior desired. The Drive Modes feature is controlled through the Uconnect system and may be accessed by performing any of the following:

- Pushing the Drive Modes button on the instrument panel switch bank.
- Selecting “SRT Modes” from the apps menu.
- Selecting “Drive Modes” from within the SRT Dashboard menu.

Within the SRT Dashboard screen, you can access Performance Pages, Drive Modes, and Race Options.



Drive Modes

- 1 — Track Mode
- 2 — Sport Mode
- 3 — Custom Mode
- 4 — Auto Mode

- **Track Mode:** Activates the configuration for typical track driving.
- **Sport Mode:** Activates the configuration for typical enthusiast driving.
- **Custom Mode:** Allows for creation of a custom configuration that is saved for quick selection of your favorite settings.

- **Auto Mode:** Utilized for typical driving conditions.

Race Options



Race Options

Press the Race Options button on the touch-screen within the SRT Dashboard menu to view the vehicle's Launch Control screen, and activate, deactivate, or adjust the RPM values for the Launch Control Shift Light features.

Valet Mode

Activate Valet Mode to lock or prevent unauthorized modifications.


Eco Mode

Eco Mode modifies the vehicle's engine and transmission settings to provide improved fuel economy at a trade-off with acceleration performance.

CHARGING & OUTLETS

USB

Your vehicle is equipped with four USB ports:



Center Console USB Ports

- 1 — USB Port 1
- 2 — USB Port 2



Rear Charge-Only USB Ports

- 1 — Charge-Only USB Port 1
- 2 — Charge-Only USB Port 2

Plugging in a mobile device to a USB port below the Uconnect screen may activate the Android Auto™ or Apple CarPlay® features.



Disabling/Enabling Android Auto™



Disabling/Enabling Apple CarPlay®

To disable Android Auto™ or Apple CarPlay®, navigate to “Device Manager” in the “Phone/Bluetooth®” section of your Uconnect settings. For further information, refer to “Android Auto™” or “Apple CarPlay®” in your Uconnect Radio Instruction Manual.

For additional information please visit UconnectPhone.com.

INSTRUMENT CLUSTER

GETTING TO KNOW YOUR INSTRUMENT CLUSTER



1. Tachometer

- Indicates the engine speed in revolutions per minute (RPM x 1000).

2. Instrument Cluster Display

- When the appropriate conditions exist, this display shows the instrument cluster display messages.

- The display always shows one of the main menu items after ignition is placed on.

3. Speedometer

- Indicates vehicle speed.

4. Temperature Gauge

The temperature gauge shows engine coolant temperature. Any reading within the normal range indicates that the engine cooling system is operating satisfactorily.

WARNING!

A hot engine cooling system is dangerous. You or others could be badly burned by steam or boiling coolant. It is recommended to call an authorized dealer for service if your vehicle overheats.

CAUTION!

Driving with a hot engine cooling system could damage your vehicle. If the temperature gauge reads "H", pull over and stop the vehicle. Idle the vehicle with the air conditioner turned off until the pointer drops back into the normal range. If the pointer remains on the "H", turn the engine off immediately and call an authorized dealer for service.

5. Fuel Gauge

- The gauge shows the level of fuel in the fuel tank when the Keyless Push Button Ignition is in the ON/RUN position.
- The fuel pump symbol points to the side of the vehicle where the fuel door is located.



NOTE:

Depending on your vehicle trim, your instrument cluster display may vary.

CONTROLLING YOUR INSTRUMENT CLUSTER DISPLAY

The instrument cluster display features a driver interactive display that is located in the instrument cluster.

This system conveniently allows the driver to select a variety of useful information by pushing the arrow buttons located on the left side of the steering wheel.



Instrument Cluster Display And Controls Location

- 1 - Instrument Cluster Display Screen
- 2 - Instrument Cluster Display Controls

For Screen Setup:

- **OK** button allows user to enter menu and submenus.

- Within each submenu layer, the **up** and **down** arrow buttons will allow the user to select the item of interest.
- Pushing the **right** arrow button will change to the next submenu layer of the menu.
- Pushing the **OK** button makes the selection. A confirmation screen will appear, returning the user to the first page of the submenu.
- Pushing the **left** arrow button will exit each submenu layer and return to the main menu.

WARNING LIGHTS AND MESSAGES

These symbols are warning/indicator lights that illuminate to signify various conditions with your vehicle, ranging from potentially critical faults to merely informing you that a feature has been engaged. Some of the symbols are optional and may or may not show.

Warning & Indicator Lights

If any of the **warning lights** illuminate in your cluster, a condition may need to be corrected or your vehicle may require service. In these situations it is recommended that you contact your local authorized dealer to schedule service.

The **indicator lights** illuminate in your cluster to indicate a feature is active.

NOTE:

Based on the vehicle trim level and current status, these lights may vary.

Warning Lights					
	Air Bag		Battery Charge		Brake
	Door Open		Electric Power Steering (EPS) Fault		Electronic Throttle Control (EPS) Fault
	Engine Coolant Temperature		Oil Pressure		Oil Temperature
	Seat Belt Reminder		Transmission Temperature		Trunk Open
	Vehicle Security		Anti-Lock Brake System (ABS)		Adaptive Cruise Control (ACC) Fault
	Cruise Control Fault		Electronic Stability Control (ESC) Active		Electronic Stability Control (ESC) Off

Warning Lights					
	Electric Park Brake (EPB)		Engine Check/Malfunction		LaneSense
	Low Fuel		Low Washer Fluid		Service AWD
	Service Forward Collision Warning (FCW)		Service LaneSense		Service Stop/Start System
	Tire Pressure Monitoring System (TPMS)				

Indicator Lights					
	Forward Collision Warning (FCW) Off		Adaptive Cruise Control (ACC) Set With No Target Detected		Adaptive Cruise Control (ACC) Set With Target
	Cruise Control Set		ECO Mode		Front Fog Lights

Indicator Lights					
	LaneSense		Parking/Headlights On		Stop/Start Active
	Sport Mode		Turn Signal		Adaptive Cruise Control (ACC) Ready
	Cruise Control Ready		Cruise Control Set		Custom Mode
	LaneSense		Speed Warning		Sport Mode
	Track Mode		Valet Mode		High Beam

INTERIOR COMFORT SETTINGS

CLIMATE CONTROLS

The Climate Control system allows you to regulate the temperature, air flow, and direction of air circulating throughout the vehicle.



Use this QR code to access your digital experience.



AUTOMATIC CLIMATE CONTROL DESCRIPTIONS AND FUNCTIONS

MAX A/C Button



Press the button on the touchscreen to set the system to maximum Air Conditioning (A/C).

A/C Button



Push the button to engage the Air Conditioning (A/C) system.

Recirculation Button



Push the button to change the system between Recirculation mode and outside air mode.

Auto Button



Push the button after setting your desired temperature and the system will maintain the set temperature.

Rear Defrost Button



Push the button to turn on the rear window defroster and heated mirrors.

Driver And Passenger Temperature Controls

Push the driver or passenger's side toggle switch upward or downward, or slide the temperature bar to adjust the driver and passenger temperature settings.



SYNC Button



Press the SYNC button on the touchscreen to synchronize the driver and front passenger temperature settings.

Blower Control



Use the small or large blower icon toggle switches or the blower bar on the touchscreen to increase or decrease the amount of air forced through the climate control system.

Mode Control



Select Mode by pressing one of the Mode buttons on the touchscreen, or the faceplate, to change the airflow distribution mode.



Panel Mode



Bi-Level Mode



Floor Mode



Mix Mode

Climate Control OFF Button



Press the button to turn the climate control system off.

AUTOMATIC TEMPERATURE CONTROL (ATC)

Automatic Operation

1. Push the AUTO button on the faceplate or the AUTO button on the touchscreen.
2. Select the desired temperature using the toggle switches or the touchscreen. The system then achieves and automatically maintains that comfort level.

NOTE:

There will be no need for you to move the temperature settings for cold or hot vehicles. The system automatically adjusts the temperature, mode, and blower speed to provide comfort as quickly as possible.

Manual Operation Override

Your Climate Control system includes manual override features. The AUTO symbol in the front ATC display will turn off when the system is in the manual mode.

CLIMATE VOICE RECOGNITION

You can adjust your vehicle's temperature hands-free while you're driving.

Push the VR button on the steering wheel. After the beep, say one of the following commands:

- "Set driver temperature to 70 degrees"
- "Set passenger temperature to 70 degrees"

Did you know: Voice Recognition for Climate may only be used to adjust the interior temperature of your vehicle. Voice Recognition will not work to adjust the heated seats or steering wheel.

FRONT HEATED SEATS



Press the heated seat button to cycle through HI, LO, and off settings.

WARNING!

- Persons who are unable to feel pain to the skin because of advanced age, chronic illness, diabetes, spinal cord injury, medication, alcohol use, exhaustion or other physical condition must exercise care when using the seat heater. It may cause burns even at low temperatures, especially if used for long periods of time.
- Do not place anything on the seat or seatback that insulates against heat, such as a blanket or cushion. This may cause the seat heater to overheat. Sitting in a seat that has been overheated could cause serious burns due to the increased surface temperature of the seat.

FRONT VENTILATED SEATS



Press the ventilated seat button to cycle through HI, LO, and off settings.

POWER FRONT SEATS

There are two power seat switches that are used to control the movement of the seat cushion and the seatback.

Push the power lumbar switch forward to increase the lumbar support. Push the switch rearward to decrease the lumbar support. Pushing upward or downward on the switch will raise and lower the position of the support.



- 1 — Adjustable Pedals Switch
- 2 — Power Seat Cushion Switch
- 3 — Power Seatback Switch
- 4 — Power Lumbar Switch

WARNING!

- Adjusting a seat while driving may be dangerous. Moving a seat while driving could result in loss of control which could cause a collision and serious injury or death.
- Seats should be adjusted before fastening the seat belts and while the vehicle is parked. Serious injury or death could result from a poorly adjusted seat belt.
- Do not ride with the seatback reclined so that the shoulder belt is no longer resting against your chest. In a collision you could slide under the seat belt, which could result in serious injury or death.

CAUTION!

Do not place any article under a power seat or impede its ability to move as it may cause damage to the seat controls. Seat travel may become limited if movement is stopped by an obstruction in the seat's path.

DRIVER MEMORY SETTINGS

This feature allows you to save up to two different memory profiles for easy recalling through a memory switch. Each memory profile saves your desired position settings for the following features:

- Driver's seat
- A set of desired radio station presets
- Power steering column (if equipped)
- Side mirrors
- Power adjustable pedals (if equipped)



To recall the memory settings for driver one or two, push the desired memory button number (1 or 2).

Programming the Memory Feature

1. Place the ignition in the ON/RUN position (do not start the engine).
2. Adjust all memory profile settings to desired preferences (i.e., seat and radio station presets).
3. Push and release the set (S) button on the memory switch, and then push the desired memory profile button (1 or 2) within five seconds. The instrument cluster display will display which memory position has been set.

Use this QR code to access your digital experience.



HEAD RESTRAINTS

Did you know your vehicle is equipped with front driver and passenger head restraints that can be adjusted two different ways?

Head restraints are designed to reduce the risk of injury by restricting head movement in the event of a rear impact. Head restraints should be adjusted so that the top of the head restraint is located above the top of your ear.



- 1 — Removal Button
2 — Adjustment Button

- To raise the head restraint, pull upward on the head restraint.
- To lower the head restraint, push the adjustment button, located at the base of the head restraint, while pushing downward on the head restraint.

Rear Head Restraints

The rear head restraints can be adjusted up or down.



- 1 — Adjustment Button

To raise the outboard head restraint, pull upward on the head restraint. To lower the head restraint, push the adjustment button, located at the base of the head restraint, and push downward on the head restraint.

WARNING!

- All occupants, including the driver, should not operate a vehicle or sit in a vehicle's seat until the head restraints are placed in their proper positions in order to minimize the risk of neck injury in the event of a crash.
- Head restraints should never be adjusted while the vehicle is in motion. Driving a vehicle with the head restraints improperly adjusted or removed could cause serious injury or death in the event of a collision.

LIGHTING OPERATION

HEADLIGHT SWITCH

The headlight switch is located on the left side of the instrument panel and is used to control your lighting.



- 1 — Push Fog Light Control
- 2 — Rotate Headlight Control
- 3 — Instrument Panel Dimmer Control
- 4 — Ambient Light Dimmer Control
- 5 — Trunk Release Button

NOTE:

Vehicles sold in Canada are equipped with a headlight switch with an AUTO and ON detent but without an OFF detent. Headlights will be deactivated when the headlight switch is placed in the parking lights position. However, the Day-time Running Lights will be activated along with the front and rear marker lights.

Headlights

Rotate the headlight control knob to select one of the available positions: O (off) position (US only), parking lights position, headlights position, or AUTO.

Fog Lights

Rotate the headlight control knob to the parking lights or low the low beam headlights and push the headlight switch.

Dimmer Control

Rotating the instrument panel dimmer up or down will adjust the brightness of the instrument panel lights. Rotating to the first detent will brighten the instrument cluster display, radio, lighted cupholders (if equipped), and overhead console. Rotating to the second detent will turn on the courtesy lights.

Ambient Dimmer Control

Rotating the instrument panel dimmer up or down will adjust the brightness of the door handle lights, map pocket lights, and ambient light located in the overhead console.

AUTOMATIC HIGH BEAMS

Did you know your vehicle can automatically switch from high beams to low beams until an approaching vehicle is out of view?

To turn on this feature:

1. Set the headlight switch to the AUTO position.
2. Make sure “Auto Dim High Beams” is set to “ON” within your Uconnect Settings.

AUTOMATIC HEADLIGHTS

With the engine running, make sure your headlight control knob is in the AUTO position; your vehicle will detect how bright it is outside and turn the headlights on/off as necessary.


AUTOMATIC HEADLIGHTS WITH WIPERS

You can have your automatic headlights automatically turn on when the wiper system is on, provided that your headlights are in AUTO mode and the engine is running. You can turn this feature on/off in the Uconnect Settings.

If you have Rain Sensing Wipers, and they are on, the headlights will automatically turn on after the wipers complete five wipe cycles within approximately one minute.

WINDSHIELD WIPERS & WASHERS

The windshield wiper/washer controls are located on the multifunction lever on the left side of the steering column.



Windshield Wiper/Washer Lever

WINDSHIELD WIPER OPERATION

Front Wipers

Rotate the end of the multifunction lever to the first detent, past the intermittent settings for low-speed wiper operation, or to the second detent past the intermittent settings for high-speed wiper operation.

Windshield Washers

To use the washer, push windshield wiper lever inward towards the steering wheel and hold.

Mist

Rotate the end of the lever downward to the MIST position and release for a single wiping cycle.

NOTE:

The mist feature does not activate the washer pump; therefore, no washer fluid will be sprayed on the windshield. The washer function must be used in order to spray the windshield with washer fluid.

WARNING!

Sudden loss of visibility through the windshield could lead to a collision. You might not see other vehicles or other obstacles. To avoid sudden icing of the windshield during freezing weather, warm the windshield with the defroster before and during windshield washer use.

CAUTION!

- Turn the windshield wipers off when driving through an automatic car wash. Damage to the windshield wipers may result if the wiper control is left in any position other than off.
- In cold weather, always turn off the wiper switch and allow the wipers to return to the parked position before turning off the engine.

(Continued)

CAUTION!

If the wiper switch is left on and the wipers freeze to the windshield, damage to the wiper motor may occur when the vehicle is restarted.

- Always remove any buildup of snow that prevents the windshield wiper blades from returning to the off position. If the windshield wiper control is turned off and the blades cannot return to the off position, damage to the wiper motor may occur.

RAIN SENSING WIPERS

This feature senses rain or snowfall on the windshield and automatically activates the wipers.

The sensitivity of the system can be adjusted with the multifunction lever. Wiper delay position 1 is the least sensitive, and wiper delay position 4 is the most sensitive.

NOTE:

The Rain Sensing feature can be turned on and off using the Uconnect system.

CRUISE CONTROL SYSTEMS

Your vehicle may be equipped with the Cruise Control system, or the Adaptive Cruise Control (ACC) system:

- Cruise Control will keep your vehicle at a constant preset speed.
- ACC will adjust the vehicle speed up to the preset speed to maintain a distance with the vehicle ahead.

NOTE:

In vehicles equipped with ACC, if ACC is not enabled, Fixed Speed Cruise Control will not detect vehicles directly ahead of you. Only one Cruise Control feature can operate at a time.

ADAPTIVE CRUISE CONTROL (ACC)

WARNING!

- Adaptive Cruise Control (ACC) is a convenience system. It is not a substitute for active driver involvement. It is always the driver's responsibility to be attentive of road, traffic, and weather conditions, vehicle speed, distance to the vehicle ahead and, most importantly, brake operation to ensure safe operation of the vehicle under all road conditions. Your complete attention is always required while driving to maintain safe control of your vehicle. Failure to follow these warnings can result in a collision and death or serious personal injury.
- The ACC system:
 - Does not react to pedestrians, oncoming vehicles, and stationary objects (e.g., a stopped vehicle in a traffic jam or a disabled vehicle).
 - Cannot take street, traffic, and weather conditions into account, and may be limited upon adverse sight distance conditions.
 - Does not always fully recognize complex driving conditions, which can result in wrong or missing distance warnings.

(Continued)

WARNING!

- Will bring the vehicle to a complete stop while following the vehicle in front and hold the vehicle for two seconds in the stop position. If the vehicle in front does not start moving within two seconds the ACC system will display a message that the system will release the brakes and that the brakes must be applied manually. An audible chime will sound when the brakes are released.

You should switch off the ACC system:

- When driving in fog, heavy rain, heavy snow, sleet, heavy traffic, and complex driving situations (i.e., in highway construction zones).
- When entering a turn lane or highway off-ramp; when driving on roads that are winding, icy, snow-covered, slippery, or have steep uphill or downhill slopes.
- When towing a trailer up or down steep slopes.
- When circumstances do not allow safe driving at a constant speed.

The buttons on the right side of the steering wheel operate the ACC system.



Adaptive Cruise Control Buttons

- 1 – CANCEL/Cancel
- 2 – Fixed Speed Cruise Control On/Off
- 3 – SET (+)/Accel
- 4 – RES/Resume
- 5 – SET (-)/Decel
- 6 – Adaptive Cruise Control (ACC) On/Off
- 7 – Distance Setting Decrease
- 8 – Distance Setting Increase

• Activate/Deactivate

- Push and release the ACC on/off button.

WARNING!

Leaving the Adaptive Cruise Control (ACC) system on when not in use is dangerous. You could accidentally set the system or cause it to go faster than you want. You could lose control and have a collision. Always leave the system off when you are not using it.

• Set A Desired ACC Speed

- When the vehicle has reached the desired speed, push the SET (+) button or SET (-) button briefly, then release.

WARNING!

In Fixed Speed Cruise Control mode, the system will not react to vehicles ahead. In addition, the proximity warning does not activate and no alarm will sound even if you are too close to the vehicle ahead since neither the presence of the vehicle ahead nor the vehicle-to-vehicle distance is detected. Be sure to maintain a safe distance between your vehicle and the vehicle ahead. Always be aware which mode is selected.

• Deactivate

- You can deactivate the ACC by pressing the ACC on/off button again, pressing the CANCEL button, or placing your vehicle's ignition in the OFF position.

• Resume Speed

- If ACC was canceled, and there is a set speed in memory, push the RES (resume) button.

WARNING!

The Resume function should only be used if traffic and road conditions permit. Resuming a set speed that is too high or too low for prevailing traffic and road conditions could cause the vehicle to accelerate or decelerate too sharply for safe operation. Failure to follow these warnings can result in a collision and death or serious personal injury.

• Vary The Speed Setting

- Once the vehicle speed has been set, you can increase the speed by pushing the SET (+) button or decrease the speed by pushing the SET (-) button.

• Setting The Following Distance In ACC

- To increase the distance setting, push the Distance Setting Increase button and release. Each time the button is pressed the distance setting increases by one bar. To decrease the distance setting, push the Distance Setting Decrease button and release. Each time the button is pushed, the distance setting decreases by one bar.

Use this QR code to access your digital experience.



GARAGE DOOR OPENER (HOMELINK®)



- The HomeLink® buttons are located in the overhead console or sunvisor and contain three optional HomeLink® channels.
 - **TO ERASE ALL SET CHANNELS:** Push and hold the two outside HomeLink® buttons for 20 seconds until the indicator flashes above the buttons.
 - **ROLLING OR NON-ROLLING?** Check your garage door opener motor in your garage for a “LEARN” or “TRAIN” button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.
1. While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.

2. Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.
3. **For Non-Rolling Code** garage door openers, watch for the indicator light to stay illuminated.
- For Rolling Code** garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.
4. **For Rolling Code** garage door openers only, firmly push and release the “LEARN” or “TRAIN” button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle three times (holding the button for two seconds each time).

WARNING!

- Your motorized door or gate will open and close while you are programming the universal transmitter. Do not program the transmitter if people or pets are in the path of the door or gate.
- Do not run your vehicle in a closed garage or confined area while programming the transmitter. Exhaust gas from your vehicle contains carbon monoxide (CO) which is odorless and colorless. Carbon monoxide is poisonous when inhaled and can cause you and others to be severely injured or killed.



If you have any problems, or require additional assistance, please call toll-free 1-800-355-3515 or visit HomeLink.com.

NOTE:

If the programming was successful, your garage door should open and close with your chosen HomeLink® button.

Use this QR code to access your digital experience.



TROUBLESHOOTING TIPS

If you are having trouble programming HomeLink®, here are some of the most common solutions:

- Replace the battery in the garage door opener hand-held transmitter.
- Push the LEARN button on the garage door opener to complete the training for a rolling code.
- Did you unplug the device for programming and remember to plug it back in?

If you have any problems, or require additional assistance, please call toll-free 1-800-355-3515 or visit HomeLink.com.

WARNING!

- Vehicle exhaust contains carbon monoxide, a dangerous gas. Do not run your vehicle in the garage while programming the transmitter. Exhaust gas can cause serious injury or death.
- Your motorized door or gate will open and close while you are programming the universal transmitter. Do not program the transmitter if people, pets or other objects are in the path of the door or gate. Only use this transmitter with a garage door opener that has a “stop and reverse” feature as required by Federal safety standards. This includes most garage door opener models manufactured after 1982. Do not use a garage door opener without these safety features.

PARKING ASSISTANCE

PARKSENSE FRONT/REAR PARK ASSIST SYSTEM

Did you know you can enable and disable the ParkSense system using the ParkSense switch, located on the center stack, below the radio screen?



Parksense Switch Location

Use this QR code to access your digital experience.



EXTERIOR OVERVIEW



1 — Refueling The Vehicle ➞ page 39

2 — Exterior Camera Location ➞ page 33

3 — Trunk Release Button ➞ page 33

EXTERIOR CAMERA VIEWS

BACK UP CAMERA

The ParkView Rear Back Up Camera allows you to see an on-screen image of the rear surroundings of your vehicle whenever the gear selector is put into REVERSE.

Manual Activation Of The Rear View Camera:

1. Press the Controls button located on the bottom of the Uconnect display.
2. Press the Back Up Camera button to turn the Rear View Camera system on.



Trunk Release Button



Passive Entry Trunk Button

TRUNK

TRUNK RELEASE BUTTON

You can open your trunk in any of the following ways:

- By pushing the trunk release button on your key fob
- By pushing the release button near the headlight switch
- By pushing the Passive Entry trunk button on the trunk lid

WARNING!

Do not allow children to have access to the trunk, either by climbing into the trunk from outside, or through the inside of the vehicle. Always close the trunk lid when your vehicle is unattended. Once in the trunk, young children may not be able to escape, even if they entered through the rear seat. If trapped in the trunk, children can die from suffocation or heat stroke.


REFUELING THE VEHICLE

1. Push the fuel filler door release switch (located in the driver's door map pocket).



Fuel Filler Door Release Switch

2. Open the fuel filler door.



Fuel Filler Location

3. Insert the fuel nozzle fully into the filler pipe.
4. Fill the vehicle with fuel – when the fuel nozzle “clicks” or shuts off the fuel tank is full.
5. Remove the fuel nozzle and close the fuel door.

WARNING!

- Never have any smoking materials lit in or near the vehicle when the fuel door is open or the tank is being filled.
- Never add fuel when the engine is running. This is in violation of most state and federal fire regulations and may cause the Malfunction Indicator Light to turn on.

(Continued)

WARNING!

- A fire may result if fuel is pumped into a portable container that is inside of a vehicle. You could be burned. Always place fuel containers on the ground while filling.


CAUTION!

To avoid fuel spillage and overfilling, do not “top off” the fuel tank after filling.

Emergency Fuel Filler Door Release


If you are unable to open the fuel filler door, use the fuel filler door emergency release located in the trunk.

1. Open the trunk.
2. Remove the access cover (located on the left side inner trim panel).




Access Cover

3. Pull the release cable.



Release Cable

ASSIST AND SOS SYSTEM — IF EQUIPPED



ASSIST And SOS Call Buttons

If equipped, the rearview mirror contains an ASSIST and an SOS button.

WARNING!

ALWAYS obey traffic laws and pay attention to the road. ALWAYS drive safely with your hands on the steering wheel. You have full responsibility and assume all risks related to the use of the features and applications in this vehicle. Only use the features and applications when it is safe to do so. Failure to do so may result in an accident involving serious injury or death.

NOTE:

- Your vehicle may be transmitting data as authorized by the subscriber.
- The ASSIST and SOS buttons will only function if you are connected to an operable LTE (voice/data) or 4G (data) network. Other Uconnect services will only be operable if your SiriusXM Guardian™ service is active and you are connected to an operable LTE (voice/data) or 4G (data) network.

ASSIST Call

The ASSIST Button is used to automatically connect you to any one of the following support centers:

- Roadside Assistance – If you get a flat tire, or need a tow, just push the ASSIST button and you will be connected to a representative for assistance. Roadside Assistance will know what vehicle you're driving and its location. Additional fees may apply for roadside Assistance.
- SiriusXM Guardian™ Customer Care – In-vehicle support for SiriusXM Guardian™.
- Vehicle Customer Care – Total support for all other vehicle issues.
- Uconnect Customer Care – Total support for Radio, Phone and NAV issues.

Making an SOS Call

WARNING!

- If anyone in the vehicle could be in danger (e.g., fire or smoke is visible, dangerous road conditions or location), do not wait for voice contact from an Emergency Services Agent. All occupants should exit the vehicle immediately and move to a safe location.
- Never place anything on or near the vehicle's operable network and GPS antennas. You could prevent operable network and GPS signal reception, which can prevent your vehicle from placing an emergency call. An operable network and GPS signal reception is required for the SOS Call system to function properly.
- The SOS Call system is embedded into the vehicle's electrical system. Do not add aftermarket electrical equipment to the vehicle's electrical system. This may prevent your vehicle from sending a signal to initiate an emergency call. To avoid interference that can cause the SOS Call system to fail, never add aftermarket equipment (e.g., two-way mobile radio, CB radio, data recorder, etc.) to your vehicle's electrical system or modify the antennas on your vehicle. IF YOUR VEHICLE LOSES BATTERY POWER FOR ANY REASON (INCLUDING DURING OR AFTER AN ACCIDENT), THE UCONNECT FEATURES, APPS AND SERVICES, AMONG OTHERS, WILL NOT OPERATE.

(Continued)

WARNING!

- Modifications to any part of the SOS Call system could cause the air bag system to fail when you need it. You could be injured if the air bag system is not there to help protect you.

1. Push the SOS Call button on the Rearview Mirror.

NOTE:

In case the SOS Call button is pushed in error, there will be a 10 second delay before the SOS Call system initiates a call to a SOS operator. To cancel the SOS Call connection, push the SOS call button on the Rearview Mirror or press the cancellation button on the Device Screen. Termination of the SOS Call will turn off the green LED light on the Rearview Mirror.

2. The LED light located next to the SOS button on the overhead console will turn green once a connection to a SOS operator has been made.
3. Once a connection between the vehicle and a SOS operator is made, the SOS Call system may transmit the following important vehicle information to a SOS operator:
 - Indication that the occupant placed a SOS Call
 - The vehicle brand

- The last known GPS coordinates of the vehicle

4. You should be able to speak with the SOS operator through the vehicle audio system to determine if additional assistance is needed.

NOTE:

Once a connection is made between the vehicle's SOS Call system and the SOS operator, the SOS operator may be able to open a voice connection with the vehicle to determine if additional assistance is needed. Once the SOS operator opens a voice connection with the vehicle's SOS Call system, the operator should be able to speak with you or other vehicle occupants and hear sounds occurring in the vehicle. The vehicle's SOS Call system will attempt to remain connected with the SOS operator until the SOS operator terminates the connection.

5. The SOS operator may attempt to contact appropriate emergency responders and provide them with important vehicle information and GPS coordinates.

WARNING!

- Ignoring the Rearview Mirror light could mean you will not have SOS Call services. If the Rearview Mirror light is illuminated, have an authorized dealer service the SOS Call system immediately.
- The Occupant Restraint Control module turns on the air bag Warning Light on the instrument panel if a malfunction in any part of the system is detected. If the Air Bag Warning Light is illuminated, have an authorized dealer service the Occupant Restraint Control system immediately.

Automatic SOS — If Equipped

Automatic SOS is a hands-free safety service that can immediately connect you with help in the event that your vehicle's airbags deploy. Please refer to your provided radio supplement for complete information.

TIRE SERVICE KIT

TIRE SERVICE KIT LOCATION

If a tire is punctured, you can make an emergency repair using the Tire Service Kit located under the load floor in the trunk.



Tire Service Kit Storage Location

The Tire Service Kit includes:

- Power Plug (located on the bottom side of the Tire Service Kit).
- Sealant bottle containing the sealant fluid.
- Sealant Hose (Clear)
- Air Pump Hose (Black).
- Air compressor, complete with pressure gauge and connectors.
- Adapters for inflating different elements.

- Adhesive label with the writing "Max. 50 mph (80 km/h)", to be attached in a position easily visible to the driver (e.g. on the dashboard) after repairing the tire.

JUMP STARTING

If your vehicle has a discharged battery, it can be jump started using a set of jumper cables and a battery in another vehicle, or by using a portable battery booster pack. Jump starting can be dangerous if done improperly, so please follow the procedures in this section carefully.

NOTE:

When using a portable battery booster pack, follow the manufacturer's operating instructions and precautions.

WARNING!


Do not attempt jump starting if the battery is frozen. It could rupture or explode and cause personal injury.

CAUTION!

Do not use a portable battery booster pack or any other booster source with a system voltage greater than 12 Volts or damage to the battery, starter motor, alternator or electrical system may occur.

PREPARATIONS FOR JUMP STARTING

The battery is stored under an access cover in the trunk. Remote battery posts are located on the right side of the engine compartment for jump starting.



Jump Starting Remote Post Locations

Remote Negative (-) Post

Remote Positive (+) Post

See the following steps to prepare for jump starting:

1. Apply the parking brake, shift the automatic transmission into PARK (P) and turn the ignition to OFF.
2. Turn off the heater, radio, and all electrical accessories.
3. Pull upward and remove the protective cover over the positive (+) battery post.
4. If using another vehicle to jump start the battery, park the vehicle within the jumper cables reach, set the parking brake and make sure the ignition is OFF.

WARNING!

- Do not allow vehicles to touch each other as this could establish a ground connection and personal injury could result.
- Take care to avoid the radiator cooling fan whenever the hood is raised. It can start anytime the ignition switch is ON. You can be injured by moving fan blades.
- Remove any metal jewelry such as rings, watch bands and bracelets that could make an inadvertent electrical contact. You could be seriously injured.
- Batteries contain sulfuric acid that can burn your skin or eyes and generate hydrogen gas which is flammable and explosive. Keep open flames or sparks away from the battery.

JUMP STARTING PROCEDURE

WARNING!

Failure to follow this jump starting procedure could result in personal injury or property damage due to battery explosion.

CAUTION!

Failure to follow these procedures could result in damage to the charging system of the booster vehicle or the discharged vehicle.

Connecting The Jumper Cables

1. Connect the positive (+) end of the jumper cable to the remote positive (+) post of the discharged vehicle.
2. Connect the opposite end of the positive (+) jumper cable to the positive (+) post of the booster battery.
3. Connect the negative (-) end of the jumper cable to the negative (-) post of the booster battery.
4. Connect the opposite end of the negative (-) jumper cable to the remote negative (-) post (exposed metallic/unpainted post of the discharge vehicle) located directly behind the underhood fuse box.

WARNING!

Do not connect the jumper cable to the negative (-) post of the discharged battery. The resulting electrical spark could cause the battery to explode and could result in personal injury.

5. Start the engine in the vehicle that has the booster battery, let the engine idle for a few minutes, and then start the engine in the vehicle with the discharged battery.
6. Once the engine is started, follow the disconnecting procedure.

Disconnecting The Jumper Cables

1. Disconnect the negative (-) end of the jumper cable from the engine ground of the vehicle with the discharged battery.
2. Disconnect the opposite end of the negative (-) jumper cable from the negative (-) post of the booster battery.
3. Disconnect the positive (+) end of the jumper cable from the positive (+) post of the booster battery.
4. Disconnect the opposite end of the positive (+) jumper cable from the remote positive (+) post of the vehicle with the discharged battery, and reinstall the protective cover.

If frequent jump starting is required to start your vehicle, you should have the battery and charging system inspected at an authorized dealer.

CAUTION!

Accessories plugged into the vehicle power outlets draw power from the vehicle's battery, even when not in use (i.e., cellular devices, etc.). Eventually, if plugged in long enough without engine operation, the vehicle's battery will discharge sufficiently to degrade battery life and/or prevent the engine from starting.

REFUELING IN EMERGENCY

The vehicle is equipped with a refueling funnel for a Capless Fuel System. The refueling funnel is located under the load floor in the trunk. If refueling is necessary, while using an approved gas can, insert the refueling funnel into the filler neck opening. Take care to open both flappers with the funnel to avoid spills.

NOTE:

In certain cold conditions, ice may prevent the fuel door from opening. If this occurs, lightly push on the outside center of the fuel door to break the ice buildup. Do not pry on the door.



Fuel Funnel Emergency Gas Can Refueling

Most gas cans will not open the flapper doors. A funnel is provided to allow emergency refueling with a gas can.

See the following steps for refueling:

1. Retrieve funnel from the spare tire storage area.
2. Insert funnel into same filler pipe opening as the fuel nozzle.



Inserting Funnel

3. Ensure funnel is inserted fully to hold flapper doors open.
4. Pour fuel into funnel opening.

CAUTION!

To avoid fuel spillage and overfilling, do not "top off" the fuel tank after filling.

5. Remove funnel from filler pipe, clean off prior to putting back in the spare tire storage area.

WARNING!

- Never have any smoking materials lit in or near the vehicle when the fuel door is open or the tank is being filled.

(Continued)

WARNING!

- Never add fuel when the engine is running. This is in violation of most state and federal fire regulations and may cause the Malfunction Indicator Light to turn on.
- A fire may result if fuel is pumped into a portable container that is inside of a vehicle. You could be burned. Always place fuel containers on the ground while filling.

FREEING A STUCK VEHICLE

If your vehicle becomes stuck in mud, sand, or snow, it can often be moved using the following steps:

1. Push the ESC OFF button to turn off the Electronic Stability Control (ESC) system, before rocking the vehicle.
2. Turn the steering wheel right and left to clear the area around the front wheels.
3. Then shift back and forth between DRIVE (D) and REVERSE (R), while gently pressing the accelerator.

NOTE:

Shifts between DRIVE and REVERSE can only be achieved at wheel speeds of 5 mph (8 km/h) or less. Whenever the transmission remains in NEUTRAL (N) for more than two seconds, you must press the brake pedal to

engage DRIVE or REVERSE. Use the least amount of accelerator pedal pressure that will maintain the rocking motion, without spinning the wheels or racing the engine.

4. Once the vehicle has been freed, push the ESC OFF button to turn on the ESC system.

CAUTION!

- Racing the engine or spinning the wheels may lead to transmission overheating and failure. Allow the engine to idle with the transmission in NEUTRAL for at least one minute after every five rocking-motion cycles. This will minimize overheating and reduce the risk of transmission failure during prolonged efforts to free a stuck vehicle.
- When “rocking” a stuck vehicle by shifting between DRIVE and REVERSE, do not spin the wheels faster than 15 mph (24 km/h), or drivetrain damage may result.
- Revving the engine or spinning the wheels too fast may lead to transmission overheating and failure. It can also damage the tires. Do not spin the wheels above 30 mph (48 km/h) while in gear (no transmission shifting occurring).

WARNING!

Fast spinning tires can be dangerous. Forces generated by excessive wheel speeds may cause damage, or even failure, of the axle and tires. A tire could explode and injure someone. Do not spin your vehicle's wheels faster than 30 mph (48 km/h) or for longer than 30 seconds continuously without stopping when you are stuck and do not let anyone near a spinning wheel, no matter what the speed.

IF YOUR ENGINE OVERHEATS

If the vehicle is overheating, it will need to be serviced by an authorized dealer.

Potential signs of vehicle overheating:

- Temperature gauge is at HOT (H)
- Strong smell of coolant
- White smoke coming from engine or exhaust
- Coolant bottle coolant has bubbles present

WARNING!

You or others can be badly burned by hot engine coolant (antifreeze) or steam from your radiator. If you see or hear steam coming from under the hood, do not open the hood until the

(Continued)

WARNING!

radiator has had time to cool. Never try to open a cooling system pressure cap when the radiator or coolant bottle is hot.

In the event it is observed that the temperature gauge is moving towards or close to the HOT (H) position, you can reduce the potential for overheating by taking the appropriate action.

- On the highways — slow down.
- In city traffic — while stopped, place the transmission in NEUTRAL (N), but do not increase the engine idle speed while preventing vehicle motion with the brakes.

- If your Air Conditioner (A/C) is on, turn it off. The A/C system adds heat to the engine cooling system and turning the A/C off can help remove this heat.
- You can also turn the temperature control to maximum heat, the mode control to floor and the blower control to high. This allows the heater core to act as a supplement to the radiator and aids in removing heat from the engine cooling system.

CAUTION!

Driving with a hot cooling system could damage your vehicle. If the temperature gauge reads “H,” pull over and stop the vehicle. Idle the vehicle with the air conditioner turned off until the pointer drops back into the normal range. If the pointer remains on the “H” and you hear continuous chimes, turn the engine off immediately and call for service.

TOWING A DISABLED VEHICLE

This section describes procedures for towing a disabled vehicle using a commercial towing service.

TOWING CONDITION	WHEELS OFF THE GROUND	ALL-WHEEL DRIVE (AWD)
Flat Tow	NONE	NOT ALLOWED
Dolly Tow	REAR	NOT ALLOWED
	FRONT	NOT ALLOWED
On Trailer	ALL	OK
When towing your vehicle, always follow applicable state and provincial laws. Contact state and provincial Highway Safety offices for additional details.		

Proper towing or lifting equipment is required to prevent damage to your vehicle. Use only tow bars and other equipment designed for this purpose, following equipment manufacturer's instructions. Use of safety chains is mandatory.

Attach a tow bar or other towing devices to main structural members of the vehicle, not to fascia/bumper or associated brackets. State and local laws regarding vehicles under tow must be observed.

NOTE:

- You must ensure that the Auto Park Brake feature is disabled before towing this vehicle to avoid inadvertent Electric Park Brake engage-

ment. The Auto Park Brake feature is enabled or disabled via the customer programmable features in the Uconnect Settings.

- Vehicles with a discharged battery, or total electrical failure when the Electric Park Brake (EPB) is engaged, will need a wheel dolly or jack to raise the rear wheels off the ground when moving the vehicle onto a flatbed.

If you must use the accessories (wipers, defrosters, etc.) while being towed, the ignition must be in the ON/RUN mode.

Note that the Safehold feature will engage the Electric Park Brake whenever the driver's door is opened (if the battery is connected, ignition is ON, transmission is not in PARK, and brake pedal is released). If you are towing this vehicle with the ignition in the ON/RUN mode, you must manually disable the Electric Park Brake each time the driver's door is opened by pressing the brake pedal and then releasing the EPB.

If the vehicle's battery is discharged, instructions on shifting the automatic transmission out of PARK so that the vehicle can be moved

➡ page 42 .

CAUTION!

- Do not use sling-type equipment when towing. Vehicle damage may occur.
- When securing the vehicle to a flatbed truck, do not attach to front or rear suspension components. Damage to your vehicle may result from improper towing.
- Ensure that the Electric Park Brake is released, and remains released, while being towed.
- Do not use a fascia/bumper mounted clamp-on tow bar on your vehicle. The fascia/bumper face bar will be damaged.

TOWING IN AN EMERGENCY

Without The Key Fob

Special care must be taken when the vehicle is towed with the ignition in the OFF mode. The only approved method of towing without the key fob is with a flatbed truck. Proper towing equipment is necessary to prevent damage to the vehicle.

Manual Park Release


To move the vehicle in cases where the transmission will not shift out of PARK (such as a depleted battery), a Manual Park Release is available.

WARNING!

Always secure your vehicle by fully applying the parking brake before activating the Manual Park Release. In addition, you should be seated in the driver's seat with your foot firmly on the brake pedal when activating the Manual Park Release. Activating the Manual Park Release will allow your vehicle to roll away if it is not secured by the parking brake, or by proper connection to a tow vehicle. Activating the Manual Park Release on an unsecured vehicle could lead to serious injury or death for those in or around the vehicle.

To use the Manual Park Release see the following steps:

1. Firmly apply the parking brake.
2. Remove the console storage bin to access the Manual Park Release lever.



Manual Park Release Cover

- Using a small screwdriver or similar tool, fish the tether strap up through the opening in the console base.
- Press and maintain firm pressure on the brake pedal.
- Insert the screwdriver into the slot in the center of the lever, and disengage the lever locking tab by pushing it to the right.
- While holding the locking tab in the disengaged position, pull the tether strap to rotate the lever up and rearward, until it locks in place in the vertical position. The vehicle is now out of PARK and can be moved. Release the parking brake only when the vehicle is securely connected to a tow vehicle.



Engaging The Lever

Your vehicle may be equipped with a tow eye that can be used to move a disabled vehicle.

Installing The Tow Eye

To install the tow eye, open the door using the a small screwdriver or similar tool. Thread the tow eye into the receptacle, making sure it is fully tightened.

The tow eye must be securely seated to the attaching bracket through the rear fascia/ bumper. If the tow eye is not securely seated to the attaching bracket, the vehicle should not be moved.



B0717000127US

Tow Eye

When using a tow eye, see the following precautions.

Tow Eye Usage Precautions

WARNING!

Stand clear of vehicles when pulling with tow eyes.

- Do not use a chain with a tow eye. Chains may break, causing serious injury or death.

(Continued)

WARNING!


- Do not use a tow strap with a tow eye. Tow straps may break or become disengaged, causing serious injury or death.
- Failure to follow proper tow eye usage may cause components to break resulting in serious injury or death.

CAUTION!

- The tow eye must only be used for roadside emergencies. Use with an appropriate device in accordance with highway code (a rigid bar or rope) to maneuver the vehicle in preparation for transport via a tow truck.
- The tow eye must not be used to move the vehicle off the road or where there are obstacles.
- Do not use the tow eyes for tow truck hookup or highway towing.
- Do not use the tow eye to free a stuck vehicle ➡ page 40 .
- Damage to your vehicle may occur if these guidelines are not followed.

ENGINE COMPARTMENT OVERVIEW

6.4L ENGINE



1 — Engine Oil Fill

2 — Brake Fluid Reservoir Access Cover

3 — Washer Fluid Reservoir Cap

4 — Power Distribution Center (Fuses)

5 — Engine Oil Dipstick

6 — Engine Air Cleaner, Filter

7 — Engine Coolant Pressure Reservoir

FLUID CAPACITIES

	US	Metric
Fuel (Approximate)		
All Engines	18.5 gal	70 L
Engine Oil With Filter		
6.4L Engine	7 qt	6.6 L
Cooling System*		
6.4L Engine	14.5 qt	13.7 L
* Includes heater and coolant recovery bottle filled to MAX level.		

FLUIDS AND LUBRICANTS

We recommend using the following fluids and lubricants:

Engine

Component	Fluid, Lubricant, or Genuine Part
Engine Coolant	We recommend using Mopar® Antifreeze/Coolant 10 Year/150,000 Mile (240,000 km) Formula OAT (Organic Additive Technology).
Engine Oil – 6.4L Engine	We recommend using Pennzoil Ultra Platinum 0W-40 or equivalent Mopar® engine oil meeting the requirements of the manufacturer Material Standard MS-12633 for use in all operating temperatures.
Fuel Selection – 6.4L Engine	91 Octane or higher, 0-15% Ethanol.

Chassis

Component	Fluid, Lubricant, Or Genuine Part
Automatic Transmission	Use only Mopar® ZF 8 & 9 Speed ATF Automatic Transmission Fluid, or equivalent. Failure to use the correct fluid may affect the function or performance of your transmission.
Brake Master Cylinder	We recommend using Mopar® DOT 3 and SAE J1703.
Rear Axle	We recommend using Mopar® OD Synthetic Gear Lubricant SAE 75W85 (API GL-5). For track use it is recommended that the axle fluid be changed every four hours of on track time.

CAUTION!

- Mixing of engine coolant (antifreeze) other than specified Organic Additive Technology (OAT) engine coolant (antifreeze), may result in engine damage and may decrease corrosion protection. Organic Additive Technology (OAT) engine coolant is different and should not be mixed with Hybrid Organic Additive Technology (HOAT) engine coolant (antifreeze) or any “globally compatible” coolant (antifreeze). If a non-OAT engine coolant (antifreeze) is introduced into the cooling system in an emergency, the cooling system will need to be drained, flushed, and refilled with fresh OAT coolant (conforming to MS.90032), by an authorized dealer as soon as possible.
- Do not use water alone or alcohol-based engine coolant (antifreeze) products. Do not use additional rust inhibitors or antirust products, as they may not be compatible with the radiator engine coolant and may plug the radiator.
- This vehicle has not been designed for use with propylene glycol-based engine coolant (antifreeze). Use of propylene glycol-based engine coolant (antifreeze) is not recommended.

SERVICING AND MAINTENANCE

MAINTENANCE PLAN

Your vehicle will remind you that it is time to take it in for scheduled maintenance.

At Every Oil Change Interval As Indicated By Oil Change Indicator System:

- Change the oil and filter.
- Rotate the tires (Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on).
- Inspect the battery and clean and tighten terminals as required.
- Inspect the CV/Universal joints.
- Inspect the brake pads, shoes, rotors, drums, and hoses.
- Inspect the engine cooling system protection and hoses.
- Inspect the exhaust system.
- Inspect the engine air filter cleaner if using in dusty or off-road conditions; replace the engine air filter cleaner as necessary.

WARNING!

- You can be badly injured working on or around a motor vehicle. Do only service work for which you have the knowledge and the right equipment. If you have any doubt about your ability to perform a service job, take your vehicle to a competent mechanic.
- Failure to properly inspect and maintain your vehicle could result in a component malfunction and affect vehicle handling and performance. This could cause an accident.

OIL CHANGE RESET

- Your vehicle is equipped with an engine oil change indicator system. The change oil message will display in the instrument cluster display for five seconds after a single chime has sounded, to indicate the next scheduled oil change interval. The engine oil change indicator system is duty cycle based, which means the engine oil change interval may fluctuate, dependent upon your personal driving style.
- Unless reset, this message will continue to display each time the ignition is cycled to the ON/RUN position.

To reset the oil change indicator after performing the scheduled maintenance, refer to the following procedure:

1. Without pressing the brake pedal, push the ENGINE START/STOP button and cycle the ignition to the ON/RUN position (do not start the engine).
2. Fully press the accelerator pedal, slowly, three times within ten seconds.
3. Cycle the ignition to the OFF position.

NOTE:

If the indicator message illuminates when you start the vehicle, the oil change indicator system did not reset. If necessary, repeat this procedure.

ENGINE BREAK-IN RECOMMENDATIONS — 6.4L

The following tips will be helpful in obtaining optimum performance and maximum durability for your new vehicle.

It is recommended for the operator to observe the following driving behaviors during the new vehicle break-in period:

0 to 100 miles (0 to 161 km):

- Do not allow the engine to operate at idle for an extended period of time.
- Press the accelerator pedal slowly and not more than halfway to avoid rapid acceleration.
- Avoid aggressive braking.
- Drive with the engine speed less than 3,500 RPM.

- Maintain vehicle speed below 55 mph (88 km/h) and observe local speed limits.

100 to 300 miles (161 to 483 km):

- Press the accelerator pedal slowly and not more than halfway to avoid rapid acceleration in lower gears (FIRST to THIRD gears).
- Avoid aggressive braking.
- Drive with the engine speed less than 5,000 RPM.
- Maintain vehicle speed below 70 mph (112 km/h) and observe local speed limits.

300 to 500 miles (483 to 805 km):

- Exercise the full engine RPM range, shifting manually at higher RPM when possible.
- Do not perform sustained operation with the accelerator pedal at wide open throttle.

- Maintain vehicle speed below 85 mph (136 km/h) and observe local speed limits.

For the first 1,500 miles (2,414 km):

- Do not participate in track events, sport driving schools, or similar activities during the first 1,500 miles (2,414 km).

NOTE:

Check engine oil with every refueling and add if necessary. Oil and fuel consumption may be higher through the first oil change interval. Running the engine with an oil level below the add mark can cause severe engine damage.

TRAILER TOWING

To maintain the New Vehicle Limited Warranty coverage, follow the requirements and recommendations in your Owner's Manual concerning vehicles used for trailer towing.

Trailer Towing Weights (Maximum Trailer Weight Ratings)

Engine/Transmission	Maximum GTW	Maximum Trailer TW (See Note)
6.4L Automatic	1,000 lb (454 kg)	100 lb (45 kg)
Refer to local laws for maximum trailer towing speeds.		

NOTE:

The trailer tongue weight must be considered as part of the combined weight of occupants and cargo, and it should never exceed the weight referenced on the Tire And Loading Information Placard.

A		
Adaptive Cruise Control (ACC) 	. . .	.29
Adaptive Cruise Control (ACC) (Cruise Control)		.28
Adding Fuel		.33
Air Conditioning		.22
Android Auto		.14
Android Auto™ 		.14
Antifreeze (Engine Coolant).		.45
Apple CarPlay® 		.13
Automatic Headlights		.26
Automatic High Beams		.26
Automatic Temperature Control (ATC) . .		.23
Automatic Transmission		
Fluid Type		.45
Axle Fluid		.45
B		
Back-Up Camera		.33
Basic Voice Commands 		.14
Brake Fluid.		.45
C		
Camera		.33
Camera, Rear		.33
Capacities, Fuel.		.45
Caps, Filler		
Oil (Engine)		.44
Cargo Light		.26
Climate Control		.22
Automatic		.22
Climate Controls 		.22
Contract, Service.		.6
Cooling System		
Cooling Capacity		.45
Selection Of Coolant (Antifreeze) . .		.45
Cruise Control (Speed Control).		.28
Customer Assistance		.5
D		
Defroster, Windshield		.22
Dimmer Control Switch		.26
Disable Vehicle Towing		.41
Driver Memory Settings 		.25
E		
Emergency, In Case Of		
Freeing Vehicle When Stuck.		.40
Jump Starting		.37
Overheating		.40
Refueling		.39
Towing		.41
Engine		.44
Compartment		.44
Coolant (Antifreeze)		.45
Fuel Requirements		.45
Jump Starting		.37
Oil		.45
Oil Filler Cap		.44
Oil Selection		.45
Overheating		.40
Exterior Lights		.26
F		
Filters		
Engine Oil		.45
Fluid, Brake		.45
Fluid Capacities.		.45
Fog Lights		.26
Freeing A Stuck Vehicle		.40
Fuel		
Octane Rating		.45
Requirements		.45
Tank Capacity		.45
G		
Garage Door Opener (HomeLink®) 		.30
H		
Headlights		
On With Wipers		.26
Switch		.26
HomeLink (Garage Door Opener)		.30

I	
Instrument Cluster	.17
Descriptions	.17
Location And Controls	.18

J	
Jump Starting	.37

K	
Key Fob.	.9
Keyless Enter'n Go™	.10
Keyless Enter 'n Go™ Passive Entry 	.10

L	
Liftgate	.33
Opening	.33
Lights	
Cargo	.26
Exterior	.26
Fog	.26
Headlights	.26

M	
Manual	
Service	.6
Media Hub	.16
Memory Seat	.24
Memory Settings	.24
MP3 Control	.16

O	
Oil Change Indicator	
Reset	.47
Oil, Engine	.45
Capacity	.45
Filter	.45
Recommendation	.45
Viscosity	.45
Operator Manual	
Owner's Manual	.6

P	
Pair/Delete A Device 	.13
Parksense Front/Rear Park Assist	
System 	.31
ParkSense System, Rear.	.31
Passive Entry.	.10
Performance Pages.	.14, 15
Power	
Seats	.24

R	
Radio	
Settings	.12
Rain Sensitive Wiper System	.27
Rear ParkSense System	.31
Remote Start (Gasoline)	.9
Remote Starting System	.9

S	
Seats	
Memory	.24
Power	.24
Second Row USB	.16
Selection Of Coolant (Antifreeze)	.45
Service Assistance.	.5
Service Contract	.6
Service Manuals	.6
SOS Call.	.35
Speed Control (Cruise Control).	.28
Steering	
Wheel, Voice Recognition	.14

T	
Temperature Control, Automatic (ATC).	.23
Tire Service Kit	.37
Towing	.48
Disabled Vehicle	.41
Towing Eyes	.42

Trailer Towing	.48
Transfer Case	
Fluid	.45
Transmission	
Fluid	.45

U

Uconnect	
Uconnect Settings.	.12
Uconnect Phone.	.12
Pair (Link) Uconnect Phone To A	
Mobile Phone	.12
Uconnect Settings	
Customer Programmable Features . .	.10
Passive Entry Programming	.10
Uconnect Settings 	.12
Uconnect System	.11
USB.	.16

V

Vehicle Settings	.12
Voice Command.	.14
Voice Recognition System (VR).	.14

W

Warning Lights And Messages.	.18
Warranty Information 	.6
Windshield Washers	.27
Windshield Wipers	.27
Wipers, Rain Sensitive.	.27





The driver's primary responsibility is the safe operation of the vehicle. Driving while distracted can result in loss of vehicle control, resulting in an accident and personal injury. FCA US LLC strongly recommends that the driver use extreme caution when using any device or feature that may take their attention off the road. Use of any electrical devices, such as cellular telephones, computers, portable radios, vehicle navigation or other devices, by the driver while the vehicle is moving is dangerous and could lead to a serious accident. Texting while driving is also dangerous and should never be done while the vehicle is moving. If you find yourself unable to devote your full attention to vehicle operation, pull off the road to a safe location and stop your vehicle. Some states or provinces prohibit the use of cellular telephones or texting while driving. It is always the driver's responsibility to comply with all local laws.

This Owner Handbook has been prepared to help you get acquainted with your new Chrysler brand vehicle and to provide a convenient reference source for common questions.

Not all features shown in this manual may apply to your vehicle. For additional information, visit mopar.com/om (USA), owners.mopar.ca (Canada) or your local Chrysler brand dealer.

DRIVING AND ALCOHOL

Drunk driving is one of the most frequent causes of accidents. Your driving ability can be seriously impaired with blood alcohol levels far below the legal minimum. If you are drinking, don't drive. Ride with a designated non-drinking driver, call a cab, a rideshare, a friend, or use public transportation.

WARNING

Driving after drinking can lead to an accident. Your perceptions are less sharp, your reflexes are slower and your judgment is impaired when you have been drinking. Never drink and then drive.

Scan to download complete Owner's
Manual, Radio and Warranty Manuals

USA



mopar.com/om

Canada



owners.mopar.ca

